

ASPEN® PUMP KIT WIRING DIAGRAM



Wiring instructions for Aspen Pumps

Mini Orange

Mini Lime

Mini Aqua

Silent+

Maxi Orange

Maxi Lime

Mini White

MITSUBISHI 230 VOLT MR. SLIM M SERIES

1. Check evaporator voltage to ensure that pump voltage is correct.
2. Install 1 amp inline fuse between evaporator and pump to protect pump and unit.
3. Connect red wire to terminal block in evaporator as shown.

NOTE: DO NOT USE SEPARATE 230 VOLT OUTLET TO POWER PUMP AS THIS IS NOT FAIL SAFE AND MAY CAUSE AN OVERFLOW!

4. Disconnect power from terminal S1 in evaporator and connect to black and gray wires from pump with a wire nut as shown. Connect purple wire from pump to terminal S1 in evaporator.

NOTE: OVERFLOW ALARM WIRE MUST BE CONNECTED TO ENSURE THAT IN CASE OF PUMP FAILURE OR BLOCKAGE IN DISCHARGE HOSE, EVAPORATOR WILL SHUT DOWN. CONNECTION OF THE OVERFLOW ALARM CIRCUIT IS MANDATORY AND FAILURE TO DO SO WILL INVALIDATE PUMP WARRANTY!

