

Használati utasítás (EN) Manua

PD Podręcznik **(DE)** Handbuch

Uživatelská příručka (FR) Manuel

ND Handleiding (JP) 使用説明書

(ES) Manual Руководство пользователя

(PT) Manual (SK) Manuá

NO Håndbok (II) Manuale

BCP-57

Quick Start Manual (English)

Download the complete manual at www.BBBparts.com

Heart rate sensor set

Herzfrequenz-Sensor Set Kit capteur cardio

Harts ag sensor set

Set de sensor de pulsómetro Sensor de frequência cardíaca

Pulzusszám mérő szenzor szett

Zestaw nadajnika pulsu Set cidel pro měření srdeční frekvence

Комплект для передачи пульса Senzor tepu srdca Pulsmåler sensorsett

HEART RATE SENSOR


1: The heart rate sensors are integrated in the soft elastic belt. For a correct heart rate measurement, the belt must be positioned slightly below your chest, directly on your skin. Make the two contact areas moist before you start your exercise. The chest belt needs to be snug to stay in place. Slide the buckles to adjust the length of the belt for a snug but comfortable fit. Press the ANT+ transmitter to the elastic belt on the two push-button connectors.

Maintenance

Remove the transmitter from the elastic belt after every use and dry the push-buttons connectors on the transmitter. Rinse the soft elastic belt under running water after every use. Wash the elastic belt regularly in a washing machine at 30°C. Use a washing pouch. Do not spin-dry, iron, dry dean or bleach the elastic belt. Do not use detergent with bleach or fabric softener. Never put the transmitter in the washing machine!

Pairing

Check the Ouick Start DigiBoard manual for the pairing procedure or download the complete manual at www.BBBoarts.com.



www.BBBPARTS.com

The specifications and designs may be changed

© BBB Bike Parts without notice. BBB has no responsibility for misprints or changed technical content.

